

Zynq[®]-7000 All Programmable SoC / AD9361 Software-Defined Radio Evaluation Kit Getting Started Guide

Version 1.0

Page 1

Copyright © 2017 Avnet, Inc. AVNET, "Reach Further," and the AV logo are registered trademarks of Avnet, Inc. All other brands are the property of their respective owners.

LIT# 5159-GSG-AES-ZSDR2-ADI-G-14_v1

Document Control

Document Version: 1.0

Document Date: 11/07/2013

Document Author(s): Avnet

Prior Version History

Version	Date	Comment
1.0	11/07/2013	Initial Release \ LL

Contents

Avnet Design Kit Technical Support Files and Downloads Web Access Instructions..	4
1.1 License Agreement.....	4
2 Introduction	7
2.1 What's Inside the Box.....	7
3 Getting Started with Zynq Software-Defined Radio	8
3.1 Overview of the 'Getting Started' Reference Design.....	8
3.2 Demo Preparations.....	9
3.3 Demo Requirements.....	9
3.4 Assembling the Hardware	10
3.5 Getting Started with Zynq Software Defined Radio.....	10
4 Restoring the SD Card image	16
5 Additional Documentation and Support.....	21
6 Next Steps	22

Avnet Design Kit Technical Support Files and Downloads Web Access Instructions

Thank you for purchasing an Avnet design kit. The technical support documents associated with this kit, including the User Guide, Bill of Materials, Schematics, Source Code and Application Notes, are available online. You, the Customer, can access these documents at any time by visiting Avnet's Design Resource Center ("DRC") at: www.avnet.com/us/drc/support

On your first visit to the DRC, you will be required to site register before you can download the documents. To get started, select the name of the manufacturer associated with your design kit from the drop down menu. A complete listing of available design kits will appear. Select the kit you purchased. Scroll to the bottom of the design kit page to access the support files. Before you download a file, you will be prompted to login. If you are an existing user, please login. If you are a new user, click on the "Need to sign-up?" text. Please complete the short registration form. Upon completion, be sure to retain your login and password information for future visits to Avnet's DRC. Logging in once, gives you unlimited access to all technical support files and downloads. You will also have the chance to request e-mail notifications whenever there are updates to your design kit.

1.1 License Agreement

THE AVNET DESIGN KIT ("DESIGN KIT" OR "PRODUCT") AND ANY SUPPORTING DOCUMENTATION ("DOCUMENTATION" OR "PRODUCT DOCUMENTATION") IS SUBJECT TO THIS LICENSE AGREEMENT ("LICENSE"). USE OF THE PRODUCT OR DOCUMENTATION SIGNIFIES ACCEPTANCE OF THE TERMS AND CONDITIONS OF THIS LICENSE. THE TERMS OF THIS LICENSE AGREEMENT ARE IN ADDITION TO THE AVNET CUSTOMER TERMS AND CONDITIONS, WHICH CAN BE VIEWED AT www.avnet.com. THE TERMS OF THIS LICENSE AGREEMENT WILL CONTROL IN THE EVENT OF A CONFLICT.

1. Limited License. Avnet grants You, the Customer, ("You" "Your" or "Customer") a limited, non-exclusive, non-transferable, license to: (a) use the Product for Your own internal testing, evaluation and design efforts at a single Customer site; (b) create a single derivative work based on the Product using the same semiconductor supplier product or product family as used in the Product; and (c) make, use and sell the Product in a single production unit. No other rights are granted and Avnet and any other Product licensor reserves all rights not specifically granted in this License Agreement. Except as expressly permitted in this License, neither the Design Kit, Documentation, nor any portion may be reverse engineered, disassembled, decompiled, sold, donated, shared, leased, assigned, sublicensed or otherwise transferred by Customer. The term of this License is in effect until terminated. Customer may terminate this license at any time by destroying the Product and all copies of the Product Documentation.
2. Changes. Avnet may make changes to the Product or Product Documentation at any time without notice. Avnet makes no commitment to update or upgrade the Product or Product Documentation and Avnet reserves the right to discontinue the Product or Product Documentation at any time without notice.
3. Limited Warranty. ALL PRODUCTS AND DOCUMENTATION ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. AVNET MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH RESPECT TO THE PRODUCTS AND

DOCUMENTATION PROVIDED HEREUNDER. AVNET SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY AGAINST INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT OF ANY THIRD PARTY WITH REGARD TO THE PRODUCTS AND DOCUMENTATION.

4. **LIMITATIONS OF LIABILITY.** CUSTOMER SHALL NOT BE ENTITLED TO AND AVNET WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND OR NATURE, INCLUDING, WITHOUT LIMITATION, BUSINESS INTERRUPTION COSTS, LOSS OF PROFIT OR REVENUE, LOSS OF DATA, PROMOTIONAL OR MANUFACTURING EXPENSES, OVERHEAD, COSTS OR EXPENSES ASSOCIATED WITH WARRANTY OR INTELLECTUAL PROPERTY INFRINGEMENT CLAIMS, INJURY TO REPUTATION OR LOSS OF CUSTOMERS, EVEN IF AVNET HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE PRODUCTS AND DOCUMENTATION ARE NOT DESIGNED, AUTHORIZED OR WARRANTED TO BE SUITABLE FOR USE IN MEDICAL, MILITARY, AIR CRAFT, SPACE OR LIFE SUPPORT EQUIPMENT NOR IN APPLICATIONS WHERE FAILURE OR MALFUNCTION OF THE PRODUCTS CAN REASONABLY BE EXPECTED TO RESULT IN A PERSONAL INJURY, DEATH OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. INCLUSION OR USE OF PRODUCTS IN SUCH EQUIPMENT OR APPLICATIONS, WITHOUT PRIOR AUTHORIZATION IN WRITING OF AVNET, IS NOT PERMITTED AND IS AT CUSTOMER'S OWN RISK. CUSTOMER AGREES TO FULLY INDEMNIFY AVNET FOR ANY DAMAGES RESULTING FROM SUCH INCLUSION OR USE.
5. **LIMITATION OF DAMAGES. CUSTOMER'S RECOVERY FROM AVNET FOR ANY CLAIM SHALL NOT EXCEED CUSTOMER'S PURCHASE PRICE FOR THE PRODUCT GIVING RISE TO SUCH CLAIM IRRESPECTIVE OF THE NATURE OF THE CLAIM, WHETHER IN CONTRACT, TORT, WARRANTY, OR OTHERWISE.**
6. **INDEMNIFICATION. AVNET SHALL NOT BE LIABLE FOR AND CUSTOMER SHALL INDEMNIFY, DEFEND AND HOLD AVNET HARMLESS FROM ANY CLAIMS BASED ON AVNET'S COMPLIANCE WITH CUSTOMER'S DESIGNS, SPECIFICATIONS OR INSTRUCTIONS, OR MODIFICATION OF ANY PRODUCT BY PARTIES OTHER THAN AVNET, OR USE IN COMBINATION WITH OTHER PRODUCTS.**
7. U.S. Government Restricted Rights. The Product and Product Documentation are provided with "RESTRICTED RIGHTS." If the Product and Product Documentation and related technology or documentation are provided to or made available to the United States Government, any use, duplication, or disclosure by the United States Government is subject to restrictions applicable to proprietary commercial computer software as set forth in FAR 52.227-14 and DFAR 252.227-7013, et seq., its successor and other applicable laws and regulations. Use of the Product by the United States Government constitutes acknowledgment of the proprietary rights of Avnet and any third parties. No other governments are authorized to use the Product without written agreement of Avnet and applicable third parties.
8. Ownership. Licensee acknowledges and agrees that Avnet or Avnet's licensors are the sole and exclusive owner of all Intellectual Property Rights in the Licensed Materials, and Licensee shall acquire no right, title, or interest in the Licensed Materials, other than any rights expressly granted in this Agreement.

9. Intellectual Property. All trademarks, service marks, logos, slogans, domain names and trade names (collectively "Marks") are the properties of their respective owners. Avnet disclaims any proprietary interest in Marks other than its own. Avnet and AV design logos are registered trademarks and service marks of Avnet, Inc. Avnet's Marks may be used only with the prior written permission of Avnet, Inc.
10. General. The terms and conditions set forth in the License Agreement or at www.em.avnet.com will apply notwithstanding any conflicting, contrary or additional terms and conditions in any purchase order, sales acknowledgement confirmation or other document. If there is any conflict, the terms of this License Agreement will control. This License may not be assigned by Customer, by operation of law, merger or otherwise, without the prior written consent of Avnet and any attempted or purported assignment shall be void. Licensee understands that portions of the Licensed Materials may have been licensed to Avnet from third parties and that such third parties are intended beneficiaries of the provisions of this Agreement. In the event any of the provisions of this Agreement are for any reason determined to be void or unenforceable, the remaining provisions will remain in full effect. This constitutes the entire agreement between the parties with respect to the use of this Product, and supersedes all prior or contemporaneous understandings or agreements, written or oral, regarding such subject matter. No waiver or modification is effective unless agreed to in writing and signed by authorized representatives of both parties. The obligations, rights, terms and conditions shall be binding on the parties and their respective successors and assigns. The License Agreement is governed by and construed in accordance with the laws of the State of Arizona excluding any law or principle, which would apply the law of any other jurisdiction. The United Nations Convention for the International Sale of Goods shall not apply.

2 Introduction

The Zynq®-7000 All Programmable SoC / AD9361 Software-Defined Radio Evaluation Kit is based on the Avnet ZedBoard™ with Xilinx Zynq-7000 All Programmable (AP) SoC. The kit features the Analog Devices AD-FMCOMMS2-EBZ FMC module, with AD9361 integrated RF Agile Transceiver. Tuned to a narrower RF range in the 2400 – 2500 MHz region, the kit is ideal for the RF engineer seeking optimized system performance meeting datasheet specifications in a defined range of RF spectrum.

This Getting Started Guide will proceed through the steps to setup the Zynq-7000 AP SoC / AD9361 Software- Defined Radio Evaluation Kit and run the out-of-box demonstration.

2.1 What's Inside the Box

- Avnet ZedBoard 7020 baseboard
 - Zynq-7000 SoC XC7Z020-CLG484-1
 - 512 MB DDR3
 - 256 Mb Spansion® Quad-SPI Flash
 - Onboard USB-JTAG Programming
 - 10/100/1000 Ethernet
 - USB OTG 2.0 and USB-UART
 - FMC expansion (low pin count)
 - Multiple displays (Analog Devices ADV7511 1080p HDMI, 12-bit VGA, 128 x 32 OLED)
- Analog Devices AD-FMCOMMS2-EBZ high-speed analog FMC Module
 - Software tunable across wide frequency range (70 MHz to 6.0 GHz)
 - Factory-tuned for optimal RF performance at 2400 – 2500 MHz¹
 - Programmable channel bandwidth at the ADC inputs ranging from <200 kHz to 56 MHz
 - RF section bypass for baseband sampling
 - Phase and frequency synchronization on both transmit and receive paths
 - Powered from single FMC connector
 - Supports MIMO radio, with less than 1 sample sync on both ADC and DAC
 - Includes schematics, layout, BOM, HDL, Linux drivers and application software
 - Supports add on cards for spectrum specific designs (PA, LNA, etc.)
- 8 GB SD card, factory-programmed
 - FAT32 partition: bootloader, devicetree blob and kernel image for system boot to UBUNTU Linux
 - EXT4 partition Linaro Ubuntu ARM root file system, Analog Devices IIO Oscilloscope
- Four Pulse 4G LTE blade antennas, SMA mount
- Micro USB cable
- USB dongle (male micro-B to female standard-A)
- Xilinx Vivado® Design Edition (device locked to XC7Z020)
- Documentation
 - Getting Started with the Zynq-7000 AP SoC / AD9361 Software-Defined Radio Evaluation Kit

¹Getting Started with the Zynq-7000 AP SoC / AD9361 Software-Defined Radio Evaluation Kit

3 Getting Started with Zynq Software-Defined Radio

The Zynq-7000 All Programmable SoC / AD9361 Software-Defined Radio Evaluation Kit comes with a 'Getting Started' demonstration design flashed onto the SD card, which enables a single-board computer on the Avnet ZedBoard running UBUNTU desktop Linux. The system includes programmable logic-based interfaces and ARM- based Linux drivers for the Analog Devices AD9361 integrated RF Agile Transceiver on the FMC module.

Two example waveforms are shown in a transmit \square receive loopback of the RF signal:

- A pair of single tones generated in the digital domain by a programmable logic-based direct digital synthesizer (DDS);
- Pre-defined waveforms from data files stored in the filesystem within the SD card.

The digital signals are driven from the Zynq SoC to the dual-DAC within the AD9361 to produce a complex analog I&Q output, then mixed with an adjustable frequency RF carrier through the quadrature modulator. The resulting RF signal is transmitted over the air through the TX-side antenna and captured at the receiver. The incoming RF signal is converted to baseband through the quadrature de-modulator, digitized through the ADC and sent to the Zynq SoC. It may be displayed in the ADI 'IIO oscilloscope' Linux application, in the time or frequency domain.

3.1 Overview of the 'Getting Started' Reference Design

The design illustrates the following capabilities of the Zynq / Analog Devices Software-Defined Radio Kit:

- Driving the 12-bit dual-DAC within the AD9361 with a programmable logic-based digital signal
- Complex mixing of baseband signal and RF local oscillator through the quadrature modulator within the AD9361
- Complex mixing to baseband of the received RF signal through the quadrature de-modulator within the AD9361
- Sampling the baseband signal at 30.72 MSPS through 12-bit dual-ADC within the AD9361
- Driving Linux-generated video content on the Analog Devices ADV7511 HDMI output interface




Figure 1: Zynq Software-Defined Radio Reference Design - Simplified Block Diagram

3.2 Demo Preparations

- a. Insert the SD Card into the ZedBoard. The 8 GB SD card is factory-programmed with the Zynq firmware, Linux kernel image, user-space application software and filesystem for a stand-alone bootable system.



Figure 2: Insert the SD Card

- b. **IMPORTANT:** Set the FMC IO voltage jumper to 2.5 V to avoid any damage to the AD-FMCOMMS2-EBZ.




Figure 3: Setting FMC IO Voltage to 2.5 V

- c. Set the boot-mode jumpers to boot from the SD card:



Figure 4: Setting boot-mode jumpers to boot from the SD card

3.3 Demo Requirements

Accessories required for this demonstration, which are not included in the kit:

- HDMI monitor
- USB mouse
- USB keyboard and USB hub (optional if you wish to type in any numeric values)

3.4 Assembling the Hardware

1. Assemble as shown below:
 - a. ZedBoard
 - b. Analog Devices AD-FMCOMMS2-EBZ
 - c. Antennas
 - d. USB dongle (male micro-B to female standard-A)
 - e. HDMI cable to display
 - f. 12 V power supply




Figure 5: Assembling the hardware for 'Getting Started Demo'

2. Connect an HDMI monitor. You may also use a DVI monitor with an HDMI to DVI-D adapter.
3. Connect a USB mouse. Optionally, you may also connect a USB keyboard through a USB hub.
4. Power up ZedBoard by turning the baseboard slider power switch ON.



Figure 6: Apply power to ZedBoard

3.5 Getting Started with Zynq Software Defined Radio

1. After a delay of approximately 45 seconds from power-on, while the bitstream is loaded from the SD card to configure the programmable logic and Linux boots on the ARM9 processor within the Zynq processing system, the UBUNTU desktop should appear and Analog Devices IIO oscilloscope application will launch.
2. Configure the following parameters in IIO Oscilloscope, leaving all others at their default values:
 - a. Capture tab

- Active channels: 'in_voltage0', de-select the other channels
- Plot type: 'Frequency Domain'
- FFT Average: 5



Figure 7: UBUNTU Desktop with Analog Devices IIO Oscilloscope

- b. From FMCComms2 tab, set the following parameters, leaving all others at their default values.
 - **TX LO Frequency** = 2400 MHz
 - Check that TX and RX LO frequencies match
 - **Save settings**




Figure 8: Setting parameters in IIO Oscilloscope

- c. From the **Capture** tab, click 'capture' (triangle icon) to start data acquisition.
 - There are actually 2 tones of same frequency, generated by TX1 and TX2.




Figure 9: Spectrum of Incoming ADC data

- d. Stop data capture and select the **FMComms2** tab.
 - Change the output frequency generated by TX2. (show signal chain BD)
 - Click **Save Settings**




Figure 10: Changing DDS Output Frequency

- e. Return to the **Capture** tab. Click the triangle icon to start data acquisition.
 - Observe the 2 tones at different frequencies.




Figure 11: Tones at Different Frequencies

We now prepare to generate pre-defined waveforms from data files stored in the filesystem within the SD card.

- f. Stop data capture and select the **FMComms2** tab.
 - For **TX1 DDS Mode**, select DAC Buffer Output




Figure 12: Generating Pre-defined Waveforms

- g. From the adjacent pull-down menu:
- From the waveforms folder, select the file 'qpskwithfilt_30.72M.txt'
 - Click 'Open'
 - Save settings




Figure 13: Selecting the Waveform Data File

- h. Return to the Capture tab.
- **Active channels:** select 'in_voltage0' and 'in_voltage1'
 - Click the triangle icon to start data acquisition
 - Observe the spectral content of the QPSK signal (real part only)




Figure 14: Spectral Content of the QPSK Signal (real part only)

This concludes the Getting Started demonstration.

Congratulations!

You have now run the Getting Started demonstration with the Zynq-7000 AP SoC / AD9361 Software-Defined Radio Evaluation Kit. Using this fully functional framework with embedded LINUX, you may now develop your wireless communications applications.

4 Restoring the SD Card image

During the course of development, should the 8 GB SD card become corrupted or otherwise need to be restored to a known good state, the directions below will restore the Zynq-7000 AP SoC / AD9361 Software-Defined Radio Evaluation Kit SD card to the factory state.

These steps will overwrite the contents of the SD card, so be certain that there is no existing data that needs to be retrieved from the SD card prior to following these steps.

The following directions were performed on a Windows 7 Professional machine, but the commands should work in a similar manner with later versions of Windows.

1. Download the image archive from ZedBoard.org. The instructions in this document assume that the archive is downloaded to a temporary folder which on this example system is under the C:\ADI\ directory. <http://www.zedboard.org/product/zynq-sdr-ii-eval>
2. Power down ZedBoard and remove the 8 GB SD card. Insert the SD card into the Windows PC.

Note: The provided image file is a byte-for-byte copy of an 8 GB SD card. Ensure the size of your target SD card is an 8 GB device.

3. Open a Windows Command Prompt session with Administrator privileges by right clicking the **Start** > **Accessories** > **Command Prompt** menu item and selecting the **Run as administrator** option.



Figure 15: Opening the Windows Command Prompt with Administrator Privileges


4. If multiple partitions exist on the SD card, each of the partitions should be removed using the diskpart utility. This will enable the entire SD card block range to be utilized for writing the image. Launch the diskpart tool from the Windows Command Prompt.



Figure 16: Launching Microsoft DiskPart

5. Discover the disk number of the SD card device by using the list disk DiskPart command. In this example, the SD card device is enumerated as the Disk 1 device.

```
DISKPART> list disk
```



Disk #	Status	Size	Free	Sys	Opt
Disk 0	Online	465 GB			
Disk 1	Online	7548 MB	3872 MB		

Figure 17: Listing the Enumerated Disk Devices

6. Select the disk listing that matches the SD card device using the select disk DiskPart command. In this example, the SD card device is enumerated as the Disk 1 device. If the SD card is listed as a different disk on your system, be sure to substitute the appropriate value here.

WARNING: Selecting the incorrect disk at this point can corrupt critical data on your local machine, be sure to check that the selected disk value is the intended device.

```
DISKPART> select disk 1
```

7. List the partitions on the currently selected SD card using the list partition DiskPart command.

```
DISKPART> list partition
```



Partition #	Type	Size	Offset
Partition 1	Primary	36 MB	4896 KB
Partition 2	Primary	7548 MB	48 MB

Figure 18: Listing the Partitions on the Selected SD Card

8. Remove the partitions from the currently selected SD card using the clean DiskPart

```
DISKPART> clean
```

command.

- Exit the DiskPart tool.

```
DISKPART> exit
```

- Extract the image contents of the archive obtained from Step 1 above using an **xz** compatible utility such as 7-Zip.




Figure 19: Extracting the Archived Image

- Launch a disk imaging utility such as Win32 Disk Imager. Click on the folder icon adjacent to the Image File entry box and set the Save as type filter option to *.* in order to make the all file extensions visible.




Figure 20: Selecting the Source Image File

12. Select the source image file **zed_fmcomms2_image_8gb** as well as the target drive device. In this example, the image is located in the **C:\ADI** folder and the target SD card is assigned to the **J:** drive.



Figure 21: Source Image File Selected

13. (Optional) Verify the integrity of the extracted image file using the Win32 Disk Imager MD5 Hash tool by clicking on the checkbox option. The checksum calculation may take a few minutes. The result from the MD5 Hash tool should match the string **bb4c6f92a1731eab79b53e5068a98019**. If the checksums do not match, the firmware




image is corrupt or out of date.²

Figure 22: Verifying Image File Integrity via MD5 Hash

14. Click the **Write** button to begin writing the source image file contents to the SD card. The SD imaging process can take around 20 to 30 minutes to complete.

² Note: checksum current at the time of writing (Nov 2013). For updates consult <http://www.zedboard.org/product/zyng-sdr-ii-eval>

15. Use Windows “safely remove” to eject the SD card.




Figure 23: Windows “safely remove” to eject the SD card

16. Replace the re-imaged SD card into ZedBoard. The Zynq-7000 SoC / AD9361 Software-Defined Radio Evaluation Kit is ready for operation with the latest SD card image.



Figure 24: Insert the re-imaged SD card into ZedBoard

This concludes the procedure of re-imaging the SD card.

5 Additional Documentation and Support

To access the most current collateral for the Zynq-7000 SoC / AD9361 Software-Defined Radio Evaluation Kit please visit the product website:

<http://www.zedboard.org/product/zynq-sdr-ii-eval>

<http://www.em.avnet.com/adizynqsdr2>

To access the Avnet Technical Community Forums, please visit the following web page:

<http://www.zedboard.org/support>

To order stand-alone AD-FMCOMMS2-EBZ high-speed analog module:

<http://www.em.avnet.com/fmcomms2>

Analog Devices AD-FMCOMMS2-EBZ high-speed analog module user guide and wiki:

<http://wiki.analog.com/resources/eval/user-guides/ad-fmcomms2-ebz>

Analog Devices AD9361 datasheet:

http://www.analog.com/AD9361_design_files

To search the Xilinx database of silicon and software questions and answers or to create a technical support case in WebCase, see the Xilinx website:

<http://www.xilinx.com/support>

6 Next Steps

Ensure Xilinx ISE Design Suite Embedded Edition 14.4 or later is installed on your computer. A voucher for licensing the Xilinx software is included with this kit. For technical support, including the installation and use of a product license file, contact Xilinx Online Technical Support at <http://www.support.xilinx.com>

Download Zynq embedded system source files for this Getting Started demonstration design as a starting point for your system customization.³

http://wiki.analog.com/resources/eval/user-guides/ad-fmcomms2-ebz/reference_hdl

Consult the Zynq-7000 SoC / AD9361 Software-Defined Radio Evaluation Kit product website for notification of technical training.

- <http://www.zedboard.org/product/zynq-sdr-ii-eval>
- <http://www.em.avnet.com/adizynqsdr>

³Zynq embedded system source files are available for subsequent customization of the reference design, but are not required to run this Getting Started demonstration. The system is stand-alone bootable from the SD card provided with the kit, which includes the bitstream within the BOOT.BIN file in the FAT32 partition.